



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**

Self-Certification Training – Structural Basics

John-Jozef “JJ” Proczka
Structural Plans Engineer
Technical Lead - Structural



Structural Codes

Admin → Load
and
Scope



We will mostly only be covering admin and loading items in this presentation



Free of their ACI overlords

Material Specific Resistance



Complete Construction Documents



Structural Drawings

- ✓ General Structural Notes
- ✓ Foundation Plan
- ✓ Floor Framing Plan
- ✓ Roof Framing Plan
- ✓ Structural Details

Supporting Documents

- ✓ Structural Calculations
- ✓ Geotechnical Report
- ✓ Geotechnical Special Inspection Certificate
- ✓ Structural Special Inspection Certificate
- ✓ Structural Observation Certificate



General Structural Notes Contents

- Building Code
- Design Live Loads
- Roof Rain Intensity –Important in Arizona.
- Wind Design Data
- Earthquake Design Data
- Geotechnical Report Number and Date
 - for minor projects without a geotechnical report see the phoenix amendment to 1803.2 or policy document/TRT
- Soil Bearing Values
- Statement of special inspections
- Structural Observations
- Deferred Submittals
- Material Specifications
- **Make sure the notes actually apply to this project**



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



Frequently Confused Structural Options



Deferred Submittals

- Identified before a permit is issued, but
- Performed and submitted after a permit is issued

Delegated Designs

- Usually performed and submitted before a permit is issued by a different engineer.



Deferred Submittals



LIMITED ITEMS CAN BE DEFERRED

- See the Phoenix deferred submittal policy document

https://www.phoenix.gov/pddsite/Documents/TRT/dsd_trt_pdf_00469.pdf

Do not defer:

- Stairs
- Guards (Guardrails)
- Structural Connections



Deferred Submittals



The construction permit drawings should:

- Identify all deferred design items,
- Show deferred items on the plans and in the details,
- Specify the design loads for the deferred items,
- Detail the supports for the deferred items.

Each deferred submittal is required to be reviewed and approved by the design team including peer reviewer before they get to the field for construction (or to the office for an office review).

Delegated Designs

Any portion of the structural design may be delegated to another qualified licensed engineer by the engineer of record.

Delegated Design drawings need to be regular design drawings and are not shop drawings!



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**




Metal Buildings and Precast Concrete



Metal Buildings and Precast Concrete Structures are an example of a DELEGATED DESIGN

Check:

- Are the drawings sealed with an ARIZONA seal?
- Are the drawings labelled “FOR CONSTRUCTION”?
- Do the drawings appear complete? Notes, Plans, Details – including the moment frame connections?
- Do the drawings look like this project?





Coordination

- Check the architectural drawings for compatibility with the structural drawings

Common Load Issues



Live Loads:

- Too low in assembly areas and corridors that serve them. IBC Table 1607.1.
- Live loads over 50 psf are posted in a conspicuous location. IBC 106.1

Dead Loads:

- Not coordinated with actual finishes and construction shown on architectural drawings.
 - Frequent mismatch between roof covering and number of layers of gypsum board.


Wind Loads:

- Exposure Category B chosen arbitrarily over Exposure Category C resulting in approximately 30% missing wind load.
- Missing parapet and overhang wind loads
- Partially enclosed buildings aren't designed for increased internal pressures




Wind Exposure Category

- Frequently misunderstood and misapplied
- Result of confusion is Exposure Category B being used in inappropriate locations, resulting in less safe buildings.
- What ASCE 7 says:
 - For each wind direction the exposure *Surface Roughness* is to be determined by the worst case 45° sector.
 - What?
 - Surface Roughness* describes one area.
 - Exposure Category describes the result of all of the *Surface Roughness* areas in the two quadrants over the required distance from the structure.
 - Many areas of Phoenix that are not developed are *Surface Roughness C*.
- Where Exposure Category B is used it is best to perform an analysis of the percentages of open spaces to confirm.



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**




North direction Exposure Category
is determined by worst case of
quadrants 8 and 1

Wind Exposure Category Cont.

Surface Roughness B: Urban and suburban areas with numerous, closely spaced obstructions that have the size of single-family dwellings or larger



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**




Roughness
C

Surface Roughness C:
Open terrain with scattered obstructions that have heights generally less than 30 feet.



Roughness
B



Wind Exposure Category Cont.



Phoenix is *Surface Roughness C* where not developed!



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**





Wind on Parapets and Overhangs

- Parapets and overhangs have high wind loads as the wind pushes on one side while it pulls on the other side.
- Buildings with parapets have much higher wind load than those without





PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**




Wind on Partially Enclosed Bldgs

- Partially enclosed buildings have much higher internal pressures
- This results in higher forces on the individual components
- Requirements for wind loads on doors and exterior windows in IBC 1709.5... yes doors and windows are actually regulated



Commentary Figure 1609.2
EFFECTS OF OPENINGS IN THE BUILDING ENVELOPE



Commentary Figure 1609.1(2)
OPENING IN EXTERIOR WALL OF BUILDING

Wind Wall Anchorage

Do walls need wind anchorage to diaphragms like they do for seismic loads?



Is your dead load larger than your wind load by the time you reach the sill plate?



(a) After hurricane Michael

(b) Before hurricane Michael (Nov 2017)

Figure 17: Jinks Middle School (Panama City) gym destroyed by Hurricane Michael ([source](#): WMBB). (a) Post-storm imagery documenting failure of end wall adjacent to parking lot (yellow dashed boxes) and tennis court (red dashed boxes). Roof at the tennis court side (blue dash boxes) is completely peeled back. (b) Multiple views of building before Hurricane Michael from Google StreetView (captured Nov 2017). Each damaged element in (a) is boxed using the same colors but solid line in (b).



Common Load Issues Continued



Earthquake Loads:

- Soil site class C chosen arbitrarily resulting in approximately 20% missing earthquake load
 - Sometimes dramatically large missing load if resulting Seismic Design Category is A used instead of B.
- Structure separation for earthquake pounding is not provided

Rain Loads:

- Rain ponding potential ignored or incorrectly checked only with strength and not stiffness.
 - ASCE 7-16 updated its definitions of susceptible bays to clarify where its required to check.
 - From 2007 to 2017 rain load building damage losses in Texas and Arizona were nearly equal to snow load losses in New England

Earthquake Building Pounding

- Building pounding occurs when two adjacent buildings collide.
- Earthquakes cause pounding when adjacent buildings have little or no separation.
- Can be extremely severe if impact takes place between floor levels
- Phoenix is lucky that its earthquake chances and motion are low, but they are not zero
- Only way to design for pounding is with separation.




PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**




Roof Rain Load and Ponding



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



- Rain causes mild pond
- Roof deflects
- More water ponds
- Roof deflections more
- Continues until failure or equilibrium from stiffness



Overlapping Information with Architectural Details

IBC 706 Fire walls – structural independence
(Section 706.2)

706.2 Structural stability.

Fire walls shall have sufficient structural stability under fire conditions to allow collapse of construction on either side without collapse of the wall for the duration of time indicated by the required fire-resistance rating or shall be constructed as double fire walls in accordance with NFPA 221.




Overlapping Information with Architectural Details




PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**

Can this detail be used at a fire wall?



Compare with this detail



Who is responsible for Fire Wall Structural Stability? - IBC 706.2


Overlapping Information with Architectural Details



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**




Fire Partition Section 708



23 JOIST BEARING DETAIL
SCALE: 3/4\"=1'-0"

Fire Barrier Section 707



23 JOIST BEARING DETAIL
SCALE: 1\"=1'-0"

**Which Detail
Should You Use?**

Overlapping Information with Architectural Details



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



IBC 704.2, 704.3, 704.4 – individual protection of structural members

- Columns
 - Individual encasement protection*
- Primary structural frame other than columns (see Chapter 2 for definition)
 - Individual encasement protection if supporting more than 2 levels of stuff
- Secondary members
 - Individual encasement or membrane protection

Overlapping Information with Architectural Details




PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



Overlapping Information with Architectural Details




PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



2 HR RATED FIREWALL AT FLOOR/CEILING

SCALE: 1 1/2" = 1'-0"



NOTES:

1. UNIT STUD WALL AND FLOOR FRAMING PER DETAIL 201.
2. CONTINUOUS 2X DOUBLE TOP PLATE WITH 16d AT 12" O.C.
3. GAP PER ARCH'L.
4. TOPPING PER PLAN.
5. 2 HOUR RATED ASSEMBLY PER ARCH'L.

NOTE:

- A. DETAIL SYMMETRICAL ABOUT GAP.
- B. AT SHEAR WALLS, PLATE AND SHEAR PANEL NAIL SPACING PER SHEAR WALL SCHEDULE.




264

PREFAB WOOD TRUSS AT WOOD STUD WALL - 2 HOUR WALL

14-1326

NO SCALE

Overlapping Information with Architectural Details



Overlapping Information with Architectural Details



Part of Cedar Rapids building falls to the ground, damages vehicle



Published: Fri Jul 24 2020

Part of Cedar Rapids building falls to the ground, damages vehicle



Published: Fri Jul 24 2020

See IBC 1404.6 through 1404.10 for heavy veneer anchorage. Frequently links to TMS 402 and TMS 602.


Roof Framing Plan



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**

IRC and Conventional Roof Construction IBC 2308


- Ceiling joists are an integral part of the construction
- They resist the thrust outwards on the walls as there is no beam at the top of the ridge



These things are
for wind uplift

Elevator Support

- Hoistway beams are only for construction and maintenance
- The guide rails infrequently take the loading of the elevators
- Elevators supported inside hoistways deliver their load to “elevator machine beams”



Picture 1: One of two sides supporting the elevator weight. The opposite side supports the drive motor and counterweight. Notice the hoist beam above. Elevators weight has traditionally been supported by the equipment and anchorages in elevator equipment rooms, above a hoistway, but these rooms are no longer common.

- Counterweights typically weigh 1.4 times the weight of the elevator

- Did you design your walls for this? Have columns for this? What happens at non-bearing walls?

- Add'l info in June 2014 structure magazine article



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



Picture 2: The same "dead" side that holds the side of the cables that do not move. This beam installed by the elevator manufacturer is supported by the hoistway wall. It is doubted this load was communicated to the building designer. This hoistway consists of both masonry and concrete walls.

Details



Check Contents:

Failures very frequently occur at connections, so ensure the important connections are provided and they make sense.





Shear Walls and Diaphragms

- That probably isn't staggered nailing in your diaphragm and shear wall panel edges typical detail



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**



Remodels and Alterations



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**


No more IBC Chapter 34. Must use IEBC.

- Show what the existing structure is and how your changes are incorporated into it.
- 5% gravity load rule clarified to 5% more load from dead, live, or snow load.
- Usually have a 10% lateral demand to capacity ratio rule.
- Older structures may not be capable of offsetting presumed live load capacity with new dead load.



Lateral Load Detailing

- Loads in the roof and floor diaphragms have a path to reach the shear walls
- Large openings in diaphragms and shear walls have reinforcement



a. Methods of bracing shall be as described in Table 2308.6.3(1) DWB, WSP, SFB, GB, PBS, PCP or HPS.




FIGURE 2308.4.4.1(1)
OPENINGS IN FLOOR AND ROOF DIAPHRAGMS

Wood Shrinkage

IBC 2304.3.3 Shrinkage effects on wood framing over three stories

Shrinkage almost exclusively takes place perpendicular to the grain for wood, not longitudinally.

Scenario sprinkler lines to roof: (3) 2x10s platform framed and (12) 2x top plates or sills.

Assume Kiln Dried (KD) wood is specified (because you don't like getting sued from green wood at 30%). Moisture content = 19%.

$$S = (3 \times 9.25'' + 12 \times 1.5'') \times (19\% - 6\%) \times 0.002$$

$S = 1.19$ inches from foundation to roof plate

- If balloon framed then = 0.47 inches.
- Mixed wood and masonry/concrete structures.

Table 1. Average Outdoor and Indoor EMC

Location	Average Outdoor EMC (%)	Average Indoor EMC (%)
Los Angeles, CA	10	9
San Diego, CA	12	10
Twentynine Palms, CA	6	6
San Francisco Bay Area	13	9
Sacramento Valley (CA)	11	8
N. Coast Red. (CA)	14	9
Sierra Nevada (CA)	11	7
San Joaquin Valley (CA)	11	8
Phoenix/Tucson, AZ	7	6

$$S = D \times M \times C$$

Where S = Shrinkage, inches


D = Dimension, inches

M = Change in moisture content, percent

C = Shrinkage coefficient, 0.0020 for Western softwood species



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**





Lateral Load Detailing



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**

- Diaphragms have collectors provided so force can reach a shear wall
- Discontinuous shear walls have adequate detailing to transfer forces. This can get very complicated if you offset walls.



Calculations

Data matches the GSN's

- Wind exposure
- Seismic data
- Soils data


Sketches of framing plans (keyed plans)


Summaries for program input and output

Hand calculations to validate connection details.



PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**





PLANNING & DEVELOPMENT
**PRESERVE
SHAPE
BUILD**

QUESTIONS?



John-Jozef “JJ” Proczka
Structural Plans Engineer
602-534-7329

john-jozef.proczka@phoenix.gov